

## Deduction Spreadsheet

<u>Supplier</u>	<u>Product</u>	<u>Face</u>	<u>Recess</u>	<u>Top</u>	
<b>WBA</b>	Rollers Blinds	None	2 W	2 W	
	Verticals	10 D	None		
	Panel Glide	10 D	None		
	Verishades	None	None	None	
	Automatic Awning	None	None	None	
	Pivot Arm	None	None	None	
	Zipscreen	None	None	None	
	Alpha Awnings	None	None	None	
<b>TWC</b>	<u>Product</u>	<u>Face</u>	<u>Recess</u>	<u>Top</u>	
	Rollers	None	4 W	4 W	
	Venetians	None	10 W - 10 D	10 W - 10 D	
	Romans	15 D	10 W - 15 D	10 W - 15 D	If roman height over 2100 make height deduction of 25mm
<b>CW Products</b>	Roller Shutters	None	5 W	None	
<b>NUE</b>	Romans	15 D	10 W - 15 D	10 W - 15 D	
	To calculate fabric for Custom Romans, calculate meterage on height + 300 NUE will supply lining				
<b>Norman</b>	Cells	Selecting correct install type as 'In (deductions will be made)' for Recess/Ceiling			
	Rollers Blinds	will result in Norman Making Deductions themselves			
	Venetians	No deductions for Face fit			
	Perfect Sheer	in short, select the correct fit type and norman will make deeductions			
	Smart Drape	None	10 W	10 W	Norman will make 13mm height deduction on Smart Drape

		<u>Face</u>	<u>Recess</u>	<u>Top</u>
<b>AWS</b>	Roller Blinds	None	4 W	4 W
		For any other product not listed, confirm with Jeff or Nick		

CW Systems		<u>Face</u>	<u>Recess</u>	<u>Top</u>
		Make sure 'Open Size' is selected, not 'Make Size'. Selecting Open Size will result in CWS Making 3mm Deductions themselves for reveal fit		
	Plantation shutters	None	None	None
	Zipscreen	None	2 W	2 W
	Straight Drop	None	2 W	2 W
	Wire Guide	None	2 W	2 W

## Curtains

Width	<u>Product</u>	<u>Face</u>	<u>Recess</u>	<u>Ceiling</u>
	Sheer Curtains	Height Only	10mm W	10mm W
	Blockout Curtians	Height Only	10mm W	10mm W

## Height Deductions

### S Wave Based on Track Type

Deductions		
<b>RK Track / S14</b>	<b>35</b>	For tracks we make in the back room
Series 58	35	For heighs over 3.5m deduct additional 5mm (40 Total)
Series 51	45	For heighs over 3.5m deduct additional 5mm (50 Total)
CT/Series 79 Track	50	For heighs over 3.5m deduct additional 5mm (55 Total)
Motorised SM20	45	For heighs over 3.5m deduct additional 5mm (50 Total)
Existing	Make size must be given by sales	

**Box Pleat, DPP, TPP, Goblet, KP, Pencil - Based on Track Type**

CT Track/ 25 Décor/ Series 79		Deductions
	45mm	10mm
	35mm	20mm
Existing track	Make size must be given by sales	

**Curtain Height Deductions based on Track Type - EVO**

	Deductions
Bella/Maxi	60
CT/Series 79 Track	45
Décor 38mm	55
Existing Track	Make size must be given by sales

**Curtain Width add ons - Box Pleat, DPP, TPP, Goblet, KP and Pencil**

Creepage is an allowed we make for pleated curtains to ensure when the curtain springs back there is enough for it reach the end of the track

Creepage                      Add 3% to Width      How to: Multiply track width by 1.03 (eg. 2000 x 1.03 = 2060)  
Note: Ensure there is a minimum 60mm of creepage added and a max of 200mm

**Finished Width = (Track Width + any Returns + any Overlap) x 1.03**

## Hook Height Guide for Curtains

### Single Curtains

Pleat Type	Fit Type	Hook Height
S-Fold	All	Empty
Box/TPP/DPP	Face	Down 45
Box/TPP/DPP	Top	Down 35
Knife Pleat	All	R7 Middle
Pencil Pleat	All	R7 Middle
Evo	All	Stackless

### Double Curtains

Pleat Type	Fit Type	Location	Hook Height
S-Fold	All	All	Empty
Box/TPP/DPP	Face	Front	Down 45
Box/TPP/DPP	Face	Rear	Down 35
Box/TPP/DPP	Top	All	Down 35
Knife Pleat	All	All	R7 Middle
Pencil Pleat	All	All	R7 Middle
Evo	All	All	Stackless